

Thera-Paw® INC.

ASSISTIVE PRODUCTS FOR ANIMALS WITH SPECIAL NEEDS
therapaw.com questions@therapaw.com

HINDLIMB DORSI-FLEX ASSIST

REDUCES KNUCKLING, ASSISTS W/ TARSAL FLEXION
mobility aid for dogs with distal hindlimb weakness



Tibial Cuff Measurement -
A) circumference around the tibia; B) the height should not exceed the caudal length from just above point of hock to the crease of the stifle when flexed

Toe Straps Measurement -
from tip of toes across back of Achilles (these are elastic/dynamic straps and have a lot of built in adjustability)

Measure-ments in Inches	BOOT Measurement Range	TIBIAL CUFF Circumference Measurement A & Cuff Height	TOE STRAPS Measurement Range
	SIZE	Paw Width Paw Length tracing in standing	Circumference & Cuff Height
XX-Small fits most weighing 15-30 lbs	2" paw width 2 1/2" paw length <i>uses size T/B Thera-Paw Boot</i>	2 1/2" – 4" circumference Cuff height 2"	5 1/2" – 6 3/4"
X-Small fits most weighing 30-40 lbs	2 1/4" paw width 2 3/4" paw length <i>uses size T/C Thera-Paw Boot</i>	3 1/2" – 4 3/4" circumference Cuff height 2 1/4"	6" – 7 3/4"
Small fits most weighing 35-65 lbs	2 1/2" paw width 3" paw length <i>uses size T/D Thera-Paw Boot</i>	4 1/4" – 6" circumference Cuff height 3"	7 1/2" – 9"
Medium fits most weighing 60-90 lbs	2 3/4" paw width 3 1/2" paw length <i>uses size T/E Thera-Paw Boot</i>	5" – 6 3/4" circumference Cuff height 3 3/4"	9 1/2" – 11"
Large fits most weighing 80-110 lbs	3" paw width 3 3/4" paw length <i>uses size T/F Thera-Paw Boot</i>	5 1/2" – 7 3/4" circumference Cuff height 4"	10 1/2" – 13"
X-Large fits most weighing 100-130 lbs	3 1/2" paw width 4 1/2" paw length <i>uses size T/G Thera-Paw Boot</i>	6 1/2" – 9" circumference Cuff height 4 3/4"	11 1/2" – 14"

Notes: The Hindlimb Dorsi-Flex Assist should provide a snug fit. Tibial cuff is adjustable. Toe straps are adjustable.